

Downunder Rollers

CARE & MAINTENANCE GUIDE

Your roller requires care and maintenance to achieve maximum life and to uphold the warranty. The following are recommended maintenance steps:

1. Do not store chemicals close to Downunder Roller, chemical spills on the lid may permanently mark.
2. Keep the Cogs clean and free of debris. Never apply lubricant on the Gear Drive/Cogs
3. Keep the framed area around the lid free of debris.
4. Regularly clean out the 'pit/housing'. It is important to keep the 'pit' area free of debris that could interfere with the operation of the roller.
5. Rollers can be cleaned down with a cloth.
6. Do not place excessive weight on the roller lid or tube.
7. Prevent water from filling the 'pit/housing' as it can damage the cover and water can potentially seep into the roller tube, making it heavy and difficult to operate.
8. Never force the roller if the cover is stuck under the coping. Lift the cover manually over the coping before winding it in to avoid damage to the cover, straps, gear housing, and roller handle.
9. With smooth surroundings like travertine, the roller can sometimes become difficult to use due to suction. In such cases, lift the cover over these areas to reduce resistance.
10. If the roller is installed far from the pool, the cover can be harder to use due to increased drag. In these cases, lift the cover over this area to reduce resistance.

Sunbather

SOLAR
POOL HEATING
& COVERS

 **1800 228 437**

Head Office: 2174 Frankston-Flinders Road, Hastings 3915 VIC
QLD Office: 25 Industrial Crescent, Willawong 4110 QLD
NSW Office: Unit 5, 6 Gladstone Road, Castle Hill 2154 NSW