## **Motorised Rollers**

**CARE & MAINTENANCE GUIDE** 



## **AR Ground | AR Wall**

Your roller requires care and maintenance to achieve maximum life and to uphold the warranty. The following are recommended maintenance steps:

- 1. Do not store chemicals close to the roller.
- 2. Keep the roller and associated frames clean. They can be cleaned down with a cloth.
- 3. Do not place excessive weight on the roller lid or tube.
- 4. Never force the roller if the cover is stuck/jammed.
- 5. If the cover is stopping short please refer to the operation guide for resetting limits.
- 6. To ensure the durability of your pool cover, it is advisable to smooth out any sharp edges on the pool coping where the cover is connected to the roller. These edges can potentially cause damage to the underside of the cover when it is being deployed or retracted.
- 7. If the roller is indoors be sure to keep area well-ventilated.
- 8. If used for domestic use, batteries in the remote should be changed every 12 months or when they don't have sufficient charge.



