

Coverroll Gear Drive Roller - Operation Guide

Putting the cover on the pool

- Remove security strap from around the cover and clip around the leg of the roller for safe keeping.
- Pick up the haul cord and walk to the other end of the pool.
- Pull the cover onto the pool.
- Put the haul cord on top of the end of the cover.

Removing the cover from the pool

- Insert the handle into the top of the gear drive.
- Wind the handle to begin winding up the cover. Always under roll for the GDT especially if enclosed in a box. (Winding crank handle clockwise to “over roll” and anti-clockwise to “under roll” cover).
- Once the cover is completely on the roller, remove handle and store safely.
- Fasten the security strap around the cover to stop it from unwinding/self shedding.

Note: In cases of strong winds and inclement weather please ensure your cover is off the pool and secured on the roller.