

Coveroll Pro Ground Roller - Operation Guide

Putting the cover on the pool

- Ensure castor wheels are locked to secure the roller.
- Remove security strap from around the cover and clip around the leg of the roller for safe keeping.
- Pick up the haul cord and walk to the other end of the pool.
- Pull the cover onto the pool.
- Put the haul cord on top of the end of the cover.

Removing the cover from the pool

- Wind the crank handle to begin winding up the cover. Note if there is a hinge section you need to fold the hinged piece onto the main cover and then under roll not over roll (winding crank handle clockwise to “over roll” and anti-clockwise to “under roll” cover)
- Once the cover is completely on the roller, fasten the security strap around the cover to stop it from unwinding/self shedding.

Note: In cases of strong winds and inclement weather please ensure your cover is off the pool and secured on the roller.

